



## INSTALLATION INSTRUCTIONS




### Tools Required



**Drill**




6mm Masonry Drill  
3.2mm HSS Drill




**Spirit level**



**Sealant Gun**



**Tape Measure**



**PH2 TYPE**  
**Screwdriver**

Please note hand tools NOT supplied.

### IMPORTANT


These instructions assume that installation is done against solid/tiled walls.

The wall plugs supplied with the installation kit are for use on solid walls. Hollow or stud-partition walls will require alternative fixings. Please consult with a reputable trades person or hardware supplier for the correct type of fixing.

It may also be necessary to consult your tiling supplier about the correct method drilling your tiles.



# MODEL : MIKOTOS (WITH SIDE PANEL)





NO.	Description	Qty
1	Wall Profile	1
2	Wall Anchor	4
3	Round Screw M4x30	4
4	T Shaped Seal	1
5	Side Panel Glass	1
6	Side Panel Rail Bracket	1




## INSTALLATION STEPS

### Step 1




# MODEL : MIKOTOS (WITH SIDE PANEL)

## Step 2




## Step 3




# MODEL : MIKOTOS (WITH SIDE PANEL)


## Step 4



Install the anti-collision block onto the guide rail first,  
and then lock the guide rail and wall base tightly




## Step 5





# MODEL : MIKOTOS (WITH SIDE PANEL)



## Step 6



Hang the door glass on the guide rail.




Install anti jump components





# MODEL : MIKOTOS (WITH SIDE PANEL)

## Step 7





## Step 8



# MODEL : MIKOTOS (WITH SIDE PANEL)

Step 9



Allow 24 hours for silicone to dry before use.

Silicone on the outside edge only

